

# Copper Crush by FusionBeads.com



Approximate finished length: 7.5 inches

## **Beads and other products needed for one bracelet:**

- 6 - 5mm Crystal Copper Swarovski Elements Crystal Bicone Beads (05BI1191)
- 4 - 6mm Crystal Golden Shadow Swarovski Elements Crystal Bicone Beads (06BI1265)
- 4 - 6mm Smoked Topaz Swarovski Elements Crystal Round Beads (06RD0132)
- 6 - 8mm Crystal Copper Swarovski Elements Crystal Round Beads (08RD0233)
- 2 - 8mm Crystal Golden Shadow Swarovski Elements Crystal Helix Beads (SC3739)
- 1 - 12x8mm Gold-Filled Oval Lobster Clasp (GF3118)
- 4 - 2x2mm Gold-Filled Crimp Beads (GF2788)
- 4 - 3.5mm Gold-Filled Crimp Bead Covers (GF2101)
- 1 - 7mm Gold-Filled 18 Gauge Closed Jump Ring (GF2738)
- 1 - 18mm Gold Vermeil 13 Gauge Closed Jump Ring (GF2639)
- 1 foot - Gold Plated Beadalon .018 diameter 19 Strand Beading Wire (SM0257)

## **Tools needed to complete the bracelet:**

- Wire cutters
- Chain nose pliers
- Crimping pliers (TL0500)

## **Beading Techniques needed to complete the necklace:**

- Crimping
- Crimp Bead Covers

## **Instructions to complete “Copper Crush” bracelet:**

### **Step 1**

Using wire cutters, cut the beading wire into two 6-inch lengths.

### **Step 2**

String one crimp bead and the loop on the lobster claw clasp onto one length of beading wire. Pass the beading wire back through the crimp bead, and crimp the crimp bead (see Crimping Technique).

### **Step 3**

Cover the crimp bead with a crimp bead cover (see Crimp Bead Covers Technique), and trim excess wire with wire cutters.

### **Step 4**

String these beads in the following sequence onto the beading wire:

- 1 – 5mm Crystal Copper bicone bead
- 1 – 8mm Crystal Copper round bead
- 1 – 6mm Smoked Topaz round bead
- 1 – 5mm Crystal Copper bicone bead
- 1 – 6mm Crystal Golden Shadow bicone bead
- 1 – 6mm Smoked Topaz round bead
- 1 – 8mm Crystal Copper round bead
- 1 – 6mm Crystal Golden Shadow bicone bead
- 1 – 5mm Crystal Copper bicone bead
- 1 – 8mm Crystal Copper round bead
- 1 – 8mm Crystal Golden Shadow Helix bead

### **Step 5**

String one crimp bead and the 18mm jump ring onto the beading wire. Pass the wire back through the crimp bead, and crimp the crimp bead. Cover the crimp with a crimp bead cover, and trim excess wire with wire cutters.

### **Step 6**

String one crimp bead and the other side of the 18mm jump ring onto the second length of beading wire. Pass the wire back through the crimp bead, and crimp the crimp bead. Cover the crimp with a crimp bead cover, and trim excess wire with wire cutters.

### **Step 7**

Repeat the stringing sequence in Step 4 in reverse.

### **Step 8**

String one crimp bead and the 7mm jump ring. Pass the wire back through the crimp bead, and crimp the crimp bead. Cover the crimp with a crimp bead cover, and trim excess wire with wire cutters.

***For step-by-step photos and instructions on these and other techniques, visit [FusionBeads.com](http://FusionBeads.com) and select Beading Techniques from the top navigation bar. You'll find more Inspiration jewelry ideas at [FusionBeads.com](http://FusionBeads.com)!***