

# Perfectly Pisces by FusionBeads.com



Approximate finished length: 18.75 inches

## **Beads and other products needed for one necklace:**

- 16 - 4mm Light Azore Swarovski Crystal Bicone Beads (04BI1124)
- 16 - 4mm Aquamarine Swarovski Crystal Bicone Beads (04BI1123)
- 16 - 4mm Blue Zircon Swarovski Crystal Bicone Beads (04BI1122)
- 16 - 4mm Turquoise Swarovski Crystal Bicone Beads (04BI1162)
- 16 - 4mm Indicolite Swarovski Crystal Bicone Beads (04BI1175)
- 8 - 6mm Aquamarine Swarovski Crystal Bicone Beads (06BI0122)
- 2 - 12mm Aquamarine Swarovski Crystal Graphic Beads (SC4231)
- 1 - 30mm Aquamarine Swarovski Crystal 3 Sprig Coral Pendant (SC4979)
- 8.5 inches - 5.5mm Natural Brass Cable Chain (CN4065)
- 1 - 11x23.8mm Natural Brass Hook and Eye Clasp (NB0138)
- 1 - 10.3mm Natural Brass Jump Ring (NB0246)
- 4 - 2mm Natural Brass Tube Crimp Bead by Vintaj (NB0638)
- 2 feet - Clear Soft Flex Beading Wire .014 Diameter (SM0310)

## **Tools needed to complete the necklace:**

- Wire cutters
- Chain nose pliers
- Crimping pliers (TL0500)

## **Beading Techniques needed to complete the necklace:**

- Crimping
- Opening and Closing a Jump Ring

*For step-by-step photos and instructions on these and other techniques, visit [FusionBeads.com](http://FusionBeads.com) and select Beading Techniques from the top navigation bar.*

## **Instructions to complete “Perfectly Pisces” necklace:**

### **Tip**

*The links of the natural brass chain are not soldered, so they can be opened and closed like jump rings.*

### **Step 1**

Using chain nose pliers to open and close the links, separate the 8.5-inch length of natural brass chain into the following increments (see Opening and Closing a Jump Ring Technique):

- 1 - 17-link length
- 1 - 11-link length
- 1 - 7-link length

### **Step 2**

Using chain nose pliers, open one end link of the 7-link length of chain, and place the loop of the natural brass hook and eye clasp onto the open chain link. Close the chain link.

### **Step 3**

Place one crimp bead and the other end chain link of the 7-link length onto a 6-inch length of beading wire. Pass the wire back through the crimp bead, and crimp the crimp bead (see Crimping Technique).

### **Step 4**

Repeat Step 3, attaching a second 6-inch length of beading wire to the same chain link.

### **Step 5**

Holding both ends of beading wire together, place one 6mm Aquamarine Swarovski crystal bicone onto the wires.

### **Step 6**

Separate the two wires and string the following beads in the sequence listed below onto **each of the wires**:

- 1 - Light Azore bicone
- 1 - Aquamarine bicone
- 1 - Turquoise bicone
- 1 - Indicolite bicone
- 1 - Blue Zircon bicone

### **Step 7**

Repeat Steps 5 and 6 one time each.

### **Step 8**

Holding both ends of the wire together, place one 12mm Aquamarine Graphic bead onto the wires.

### **Step 9**

Separate the two wires and repeat Step 6, reversing the stringing sequence.

### **Step 10**

Repeat Step 5 once, Step 9 once, then Step 5 once more.

### **Step 11**

Place one crimp bead onto the end of one of the wires. Place the end link of the 11-link length of chain onto the wire, pass the wire back through the crimp bead, crimp the crimp bead, and trim excess wire with wire cutters.

### **Step 12**

Repeat Step 11 with the other length of beading wire.

### **Step 13**

Open one 10.3mm brass jump ring. Use the jump ring to connect the Aquamarine Swarovski crystal 3 sprig pendant to the open end link of the 11-link length of chain. Close the jump ring.

### **Step 14**

Repeat Steps 3 - 12, connecting the other end of the 11-link length of chain to one end of the 17-link length of chain with the 2-strand pattern of crystals.

**Step 15**

Using chain nose pliers, open the other end chain link of the 17-link length of chain. Place the eye side of the hook and eye clasp onto the open link of chain, and close the chain link.

**For more Inspiration jewelry ideas and to meet all your beading needs, visit [FusionBeads.com](http://FusionBeads.com)!**