

Modern Movement by FusionBeads.com



Approximate finished length: 2.5 inches

Beads and other products needed for one pair of earrings:

- 6 - 23x11mm Crystal AB Swarovski Crystal Modular Beads (SC4888)
- 8 inches - 1.9mm Silver Base Metal Chain (CN4008)
- 1 pair - 15mm Sterling Silver French Hoops with 2mm Beads (SS2607)
- 2 - 5mm Sterling Silver Jump Rings (SS3920)
- 4 inches - 20 Gauge Sterling Silver Half Hard Wire (SW0115)

Tools needed to complete the earrings:

- Wire cutters
- Chain nose pliers
- Round nose pliers

Beading Techniques needed to complete the earrings:

- Simple Loop
- Opening and Closing a Jump Ring
- Cutting Chain Efficiently

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar.

Instructions to complete “Modern Movement” earrings:

Step 1

Using wire cutters, cut the 4-inch length of silver base metal chain into four 1-inch lengths (see Cutting Chain Efficiently Technique).

Step 2

Using round nose pliers and a 2-inch length of sterling silver wire, turn a simple loop (see Simple Loop Technique) at one end of the wire, placing one end of one 1-inch length of cut chain onto the loop before completing it.

Step 3

Place 3 23x11 mm Crystal AB Swarovski crystal Modular beads onto the open end of the wire, turn a simple loop at the open end of the wire and place one end of a second 1-inch length of cut chain onto the loop before completing it.

Step 4

Using chain nose pliers, open one 5mm jump ring (see Opening and Closing a Jump Ring Technique). Place both open ends of the two lengths of chain onto the jump ring, then place the loop of one sterling silver ear wire onto the jump ring. Close the jump ring.

Step 5

Repeat Steps 2 - 4 for the second earring.

For more Inspiration jewelry ideas and to meet all your beading needs, visit FusionBeads.com!