

For Mama by FusionBeads.com



Approximate finished length: 3 inches

Beads and other products needed for one pair of earrings:

- 2 - 4mm Aquamarine Swarovski Elements Crystal Bicone Beads (04BI1123)
- 2 - 4mm Peridot Swarovski Elements Crystal Bicone Beads (04BI1116)
- 2 - 4mm Emerald Swarovski Elements Crystal Bicone Beads (04BI1120)
- 2 - 6mm Aquamarine Swarovski Elements Crystal Silver Plated Channel Charms (RI1572)
- 2 - 6mm Peridot Swarovski Elements Crystal Silver Plated Channel Charms (RI1582)
- 2 - 6mm Emerald Swarovski Elements Crystal Silver Plated Channel Charms (RI1575)
- 1 pair - 12mm Sterling Silver French Ear Wires with 2mm Ball (SS4036)
- 6 inches - 1.5mm Sterling Silver Cable Chain (CN5309)
- 6 - 22 gauge Sterling Silver 1.5 inch Eye Pins (SS4010)

Tools needed to complete the earrings:

- Round nose pliers
- Chain nose pliers
- Wire cutters

Beading Techniques needed to complete the earrings:

- Attaching an Ear Wire
- Opening and Closing a Jump Ring
- Cutting Chain Efficiently
- Simple Loop

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar.

Instructions to complete “For Mama” earrings:

Step 1

Cut the chain into the following lengths (see Cutting Chain Efficiently Technique):

2 – 0.25” lengths

2 – 1” lengths

2 – 1.75” lengths

Set aside one of each length for the second earring.

Step 2

Open the loop on one eye pin (see Opening and Closing a Jump Ring Technique). Attach one end link of one 1.75-inch length of chain onto the loop, and close the loop.

Step 3

Place one 4mm Emerald crystal bicone bead onto the eye pin from Step 2, making one unit. Turn a simple loop (see Simple Loop Technique) at the open end of the eye pin. Attach the loop just made to the loop on one Emerald crystal channel charm.

Step 4

Open the loop on one ear wire (see Attaching an Ear Wire Technique), and attach it to the unattached end link of chain. Leave the loop open.

Step 5

In the same manner as in Steps 2 – 3, attach the specified chain lengths to simple loop units connected to crystal channel charms:

1” length of chain, 4mm Peridot bicone bead, Peridot channel charm

0.25” length of chain, 4mm Aquamarine bicone bead, Aquamarine channel charm

Step 6

In the same manner as in Step 4, attach the unattached end links of the chains to the loop on the ear wire. Close the loop.

Step 7

Repeat Steps 2 – 6 for the second earring.

For more Inspiration jewelry ideas and to meet all your beading needs, visit FusionBeads.com!