

Sparkle Stack by FusionBeads.com



Beads and other products needed for three rings:

- 1 - 3mm Smoked Topaz Swarovski Elements Crystal Rose Montee (EW1087)
- 1 - 3mm Light Colorado Topaz Swarovski Elements Crystal Rose Montee (EW1089)
- 1 - 6mm Topaz Swarovski Elements Crystal Rose Montee (EW1127)
- 6 inches - 16 gauge Fine Silver Wire (FW0105)
- 15 inches - 26 Gauge Silver-Filled Dead Soft Wire (WW0125)

Tools needed to complete the rings:

- Chain nose pliers
- Tronex Ergonomic Razor Flush Cutter - Standard Handle (TL2164)
- Butane Micro Torch
- Cool Cup Soldering Cup w/ Tweezers
- Ring Mandrel
- Rock Tumbler, single 3 lb capacity
- Stainless Steel Shot

Beading Techniques needed to complete the rings:

Fusing a Fine Silver Ring Band

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar.

Instructions to complete “Sparkle Stack” rings:

Step 1

Using 2 inches of 16 gauge fine silver wire, make a fused ring of the desired size (see Fusing a Fine Silver Ring Band Technique).

Step 2

Repeat Step 1 twice, making a total of three rings.

Step 3

Anchor a 5-inch length of 26 gauge silver-filled wire to one ring. Wrap the wire tightly around the ring for about 1/8-inch. String one crystal rose montee onto the wire, and pull it close to the ring so that the back side is flush against the outer edge of the ring. Continue wrapping the wire for another 1/8-inch. Trim the wire, and tuck the tail closely against the ring.

Step 4

Repeat Step 3 with each of the remaining rings and rose montees.

For more Inspiration jewelry ideas and to meet all your beading needs, visit FusionBeads.com!