

Scarlet at Dusk Necklace by FusionBeads.com



Approximate finished length: 19 inches

Beads and other products needed for one necklace:

- 6 - 6mm Jet Swarovski Elements Crystal Round Beads (06RD0135)
- 10 - 6mm Siam Swarovski Elements Crystal Round Beads (06RD0111)
- 6 - 8mm Light Siam Swarovski Elements Crystal Round Beads (08RD0110)
- 2 - 10.5mm Light Siam Swarovski Elements Crystal Rivoli Stones (SC7253)
- 2 - 14mm Siam Swarovski Elements Crystal Rivoli Stones (SC4831)
- 1 - 14mm Jet Swarovski Elements Crystal Rivoli Stones (SC5256)
- 2 - 10.5mm Light Siam Swarovski Elements Crystal Rivoli Stones (SC7253)
- 2 - 21x16.5mm Rhodium Plated Pewter Faceted Rivoli Links by TierraCast (SP2461)
- 3 - 25x17mm Rhodium Plated Pewter Faceted Rivoli Links by TierraCast (SP2462)
- 1 - 16x12mm Antique Silver Plated Pewter Toggle Clasp by TierraCast® (SP2128)
- 4 - 5mm Silver Plated Base Metal 20 Gauge Open Jump Rings (BM2759)
- 5.5 feet - 22 Gauge Non-Tarnish Silver Artistic Wire (AW2084)

Tools needed to complete the necklace:

- Round nose pliers
- Chain nose pliers
- Wire cutters
- 5 Minute Epoxy (TL1938)
- Toothpick
- Disposable tray or paper plate

Beading Techniques needed to complete the necklace:

- Opening and Closing a Jump Ring
- Wire Wrapped Link
- Gluing Swarovski Elements Crystal Rivoli Stones into a Rivoli Component

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar.

Instructions to complete “Scarlet at Dusk” necklace:

Step 1

Mix the two parts of the 5 Minute Epoxy (see Gluing Swarovski Elements Crystal Rivoli Stones into a Rivoli Component Technique). Apply epoxy to the center of one 21x16.5mm Rivoli link. Place one 10.5mm Light Siam crystal Rivoli stone onto the epoxy, and press firmly. Allow to dry.

Step 2

In the same manner as in the previous step, adhere the remaining Rivoli stones to the specified Rivoli links:

- 1 – 10.5mm Light Siam Rivoli stone to one 21x16.5mm Rivoli link
- 1 – 14mm Siam Rivoli stone to one 25x17mm Rivoli link
- 1 – 14mm Siam Rivoli stone to one 25x17mm Rivoli link
- 1 – 14mm Jet Rivoli stone to one 25x17mm Rivoli link

Step 3

Open one jump ring (see Opening and Closing a Jump Ring Technique). Use the jump ring to attach one loop on one Light Siam 21x16.5mm Rivoli link to one loop on one Siam 25x17mm Rivoli link. Close the jump ring.

Step 4

In the same manner as in the previous step, use jump rings to connect the links in the following sequence into a continuous chain:

- 1 – Siam 25x17mm Rivoli link (from the previous step)
- 1 – Jet 25x17mm Rivoli link
- 1 – Siam 25x17mm Rivoli link
- 1 – Light Siam 21x16.5mm Rivoli link

Step 5

Using a 3-inch length of wire, make a wire wrapped link (see Wire Wrapped Link Technique) with one 8mm Light Siam crystal round bead. Connect one side of this wire wrapped link to the unattached loop on one 21x16.5mm Rivoli link, and complete the other side of the wire wrapped link without connecting it to anything.

Step 6

Using a 3-inch length of wire, make a wire wrapped link with one 8mm Light Siam crystal round bead. Connect one side of this wire wrapped link to the open loop on the wire wrapped link from the previous step, and complete the other side of the wire wrapped link without connecting it to anything.

Step 7

In the same manner as in Steps 5 – 6, continue making wire wrapped links using one bead per link and connecting them in the following sequence:

- 1 – 8mm Light Siam round bead
 - 1 – 6mm Siam round bead
 - 1 – 6mm Siam round bead
 - 1 – 6mm Siam round bead
 - 1 – 6mm Siam round bead
 - 1 – 6mm Siam round bead
 - 1 – 6mm Siam round bead
 - 1 – 6mm Jet round bead
 - 1 – 6mm Jet round bead
 - 1 – 6mm Jet round bead
- the loop on one side of the toggle clasp

Step 8

Repeat Steps 5 – 7 on the other side of the necklace.

For more Inspiration jewelry ideas and to meet all your beading needs, visit FusionBeads.com!