

# Tickle Me Turquoise by FusionBeads.com



Approximate finished length: 8 inches

## **Beads and other products needed for one bracelet:**

- 15 - 3mm Light Turquoise Swarovski Elements Crystal Bicone Beads (03BI1417)
- 14 - 10mm Light Turquoise Swarovski Elements Crystal Round Beads (10RD0182)
- 1 - 19.5x14.5mm Antique Rhodium Plated Pewter Butterfly Toggle Clasp by TierraCast® (SP2222)
- 2 - 2x2mm Sterling Silver Crimp Beads (SS4047)
- 2 - 3.5mm Sterling Silver Crimp Bead Covers (SS2103)
- 10 inches - Clear Soft Flex Wire .014 diameter (SM0310)

## **Tools needed to complete the bracelet:**

- Wire cutters
- Crimping pliers (TL0500)

## **Beading Techniques needed to complete the bracelet:**

- Crimping
- Crimp Bead Covers

## **Instructions to complete “Tickle Me Turquoise” bracelet:**

### **Step 1**

Place one crimp bead and the loop on one side of the toggle clasp onto a 10-inch length of beading wire. Pass the wire back through the crimp bead, and crimp the crimp bead (see Crimping Technique).

### **Step 2**

Cover the crimp bead with a crimp bead cover (see Crimp Bead Covers Technique), and trim excess wire with wire cutters.

### **Step 3**

String these beads in the following sequence onto the beading wire:

1 – 3mm Light Turquoise bicone bead

1 – 10mm Light Turquoise round bead

Repeat the sequence 13 times, adding one 3mm Light Turquoise bicone bead after the last repeat.

### **Step 4**

String one crimp bead and the loop on the other side of the clasp onto the beading wire. Pass the wire back through the crimp bead, and crimp the crimp bead. Cover the crimp with a crimp bead cover, and trim excess wire with wire cutters.

*For step-by-step photos and instructions on these and other techniques, visit [FusionBeads.com](http://FusionBeads.com) and select Beading Techniques from the top navigation bar. You'll find more Inspiration jewelry ideas at [FusionBeads.com](http://FusionBeads.com)!*