

Vintage Chic by FusionBeads.com



Approximate finished length: 1 inch

Beads and other products needed for one pair of earrings:

- 2 - Swarovski Crystal Rivoli Stone - 1122 - Crystal Rose Patina - 12mm (SK1428)
- 2 - Pewter Beaded Round Glue-In Rivoli Charm by TierraCast® - Antique Copper - 20mm (CP6262)
- 1 pair - Niobium French Ear Wire with Large Front Loop by TierraCast® - Copper - 21mm (BM0202)

Tools needed to complete the earrings:

- Chain nose pliers
- E6000 Adhesive 0.18 oz. Tube (TL2921)



Beading Techniques needed to complete the earrings:

- Attaching an Ear Wire
- Gluing Swarovski Elements Crystal Rivoli Stones into a Rivoli Component

Instructions to complete “Vintage Chic” earrings:

Step 1

Apply a drop of E6000 adhesive to the center of one Rivoli charm (see Gluing Swarovski Elements Crystal Rivoli Stones into a Rivoli Component Technique).



Step 2

Place one crystal Rivoli stone onto the adhesive, and press firmly. Allow to dry.



Step 3

Open the loop on one ear wire (see Attaching an Ear Wire Technique), and attach it to the loop on the charm.



Step 4

Close the loop.

**Step 5**

Repeat Steps 1 – 4 for the second earring.



*For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select *Beading Techniques* from the top navigation bar. You'll find more *Inspiration jewelry ideas* at FusionBeads.com!*