

Crystal AB Rivoli by FusionBeads.com



Approximate finished length: 1 inch

Beads and other products needed for one pair of earrings:

2 - 12mm Crystal AB Swarovski Crystal Rivoli Stone - 1122 (SC5225)
2 - Pewter Faceted Round Rivoli Charm by TierraCast - Rhodium - 19mm (SP2515)
1 pair - 9mm Silver-Filled Ear Wire with Front Loop by TierraCast (SF0424)

Tools needed to complete the earrings:

Chain nose pliers
E6000 Adhesive 0.18 oz. Tube (TL2921)

Beading Techniques needed to complete the earrings:

Gluing Swarovski Elements Crystal Rivoli Stones into a Rivoli Component
Attaching an Ear Wire

Instructions to complete “Crystal AB Rivoli” earrings:

Step 1

Apply a drop of E6000 adhesive to the center of one Rivoli charm (see Gluing Swarovski Elements Crystal Rivoli Stones into a Rivoli Component Technique).

Step 2

Place one crystal Rivoli stone onto the adhesive, and press firmly. Allow to dry.

Step 3

Open the loop on one ear wire (see Attaching an Ear Wire Technique), and attach it to the loop on the charm.

Step 4

Close the loop.

Step 5

Repeat Steps 1 – 4 for the second earring.

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar. You'll find more Inspiration jewelry ideas at FusionBeads.com!