

Modern Chrome by FusionBeads.com



Approximate finished length: 21 inches

Beads and other products needed for one necklace:

- 5 - 4mm Crystal Light Chrome 2X Swarovski Crystal Bicone Bead – 5328 (04B11497)
- 1 - 22mm Crystal Light Chrome Swarovski Crystal Metal Cap Pear Shape Pendant - 6565 (SK3160)
- 18 inches - 2mm Sterling Silver Flat Cable Chain (CN0270)
- 1 - Base Metal Lobster Claw Clasp - Silver - 12mm (BM3150)
- 1 - 4mm Silver Plated Base Metal 20 Gauge Open Jump Ring (BM2747)
- 2 - 6mm Silver Plated Base Metal 20 Gauge Open Jump Ring (BM2767)
- 5 inches - Round Artistic Wire - Tarnish Resistant Silver - 24 gauge (AW2117)

Tools needed to complete the necklace:

Chain nose pliers
Round nose pliers
Wire cutters

Beading Techniques needed to complete the necklace:

Wire Wrapped Link
Opening and Closing a Jump Ring

Instructions to complete “Modern Chrome” necklace:

Step 1

Cut your chain into the following lengths:

1 – 7-inch length

1 – 12-inch length

Step 2

Make a wire wrapped link (see Wire Wrapped Link Technique) with a 5-inch length of wire and 5 - 4mm light chrome bicones. Attach one side of the link to one end of the 7-inch length of chain and the other end of the link to the 12-inch length of chain.

Step 3

Open one 6mm jump ring (see Opening and Closing a Jump Ring Technique). Attach the jump ring to the pendant and the 12-inch length of chain about 2-inches from the wire wrapped link. Close the jump ring.

Step 4

Open one 4mm jump ring. Use the jump ring to attach the loop on the lobster claw clasp to the unattached end of the 7-inch length chain. Close the jump ring.

Step 5

Open a second 6mm jump ring and attach it to the unattached end of the 12-inch length of chain. Close the jump ring.

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar. You'll find more Inspiration jewelry ideas at FusionBeads.com!