

Mint To Be by FusionBeads.com



Approximate finished length: 4 inches

Beads and other products needed for one garden marker:

1 - DIY Garden Marker Project Kit By ImpressArt (TL3273)

Tools needed to complete the garden marker:

Juniper Stamp Set by ImpressArt - 3mm - Upper Case Letter (TL3036)

2 Inch Steel Bench Block With Rubber Feet By ImpressArt (TL3154)

1 Lb Brass Metal Stamping Hammer (TL2965)

Stamp Enamel Marker by ImpressArt (TL3209)

Stamp Guides Sticker Book By ImpressArt (TL3214)

Pro Polish Pads (TL0617)

Beading Techniques needed to complete the garden marker:

Metal Stamping

Antiquing Silver

Instructions to complete “Mint To Be” garden marker:

Step 1

Tape the stamping blank into place on the bench block. Put the straight stamp guide on the stamping blank so it's covering ¼" along the bottom of the blank. Using the hammer and the stamp sets, stamp the words “MINT TO BE” (or any words of your choice) into the stamping blank (see Metal Stamping Technique).

Step 2

Using a stamp enamel marker, darken the stamped area (see Antiquing Silver Technique).

Step 3

Remove any excess ink around the stamped area with a Pro Polish Pad.

For step-by-step photos and instructions on these and other techniques, visit FusionBeads.com and select Beading Techniques from the top navigation bar. You'll find more Inspiration jewelry ideas at FusionBeads.com!